



Fitting Instructions for RAD0097BK/TI Radiator Guard Honda VFR1200 AUTO ONLY 2010-



**In This Kit There Should Be
1x Radiator Guard (RAD0097)
2 x Cable/Zip Ties
2x 100mm Lengths of Foam**

- To fit the radiator guard you will need to remove the front radiator surround and both side panels.
- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator. The cable ties go through the slots at the top of the radiator guard and around the mounting brackets of the radiator as shown above right. At the bottom, bolt the radiator guard to the original mountings bracket using the original bolts as shown above left. When the guard is in position tighten the cable tie.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing
Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



FRANCE

Instructions de montage de la protection de radiateur RAD0097BK/TI Honda VFR1200 AUTO seulement 2010-



Dans ce kit vous devez trouver:
1x protection de radiateur (RAD0097).
2x 100mm de mousse auto adhésive.
2x Câble de serrage.

- Pour fixer la protection de radiateur, vous devrez enlever les carénages latéraux et l'entourage du radiateur.
- Couper des morceaux de mousse de 10 mm environ et placez ceux-ci sur la grille de protection (les mettre entre la grille et le radiateur).
- Placez la protection de radiateur sur la moto et fixez la partie supérieure à l'aide des 2 câbles en plastique. Voir Photo
- Fixez la fixation basse à l'aide du système de fixation d'origine voir la photo de gauche.
- Lorsque que la protection est en place, serrer les 2 câbles.
- Remonter les carénages.



**Montageanleitung für den RAD0097BK/TI Kühlerschutz
Honda VFR1200 AUTO AUSSCHLISSLICH MODELL 2010-**



**Dieser Kit enthält:
1x Kühlerschutz (RAD0097)
2 x Kabelbinder
2x 100mm Schaumstoffstreifen**

- Entfernen Sie zuerst die vordere Verkleidung um den Kühler und beide Seitenverkleidungen.
- Um den Kühlerschutz am Motorrad zu montieren, schneiden Sie zuerst die mitgelieferten Schaumstoff-Streifen in 10 mm breiten Streifen und kleben Sie diese auf der Rückseite des Kühlerschutzrahmens, so dass sie zwischen dem Kühlerschutz und dem Kühler angebracht sind. Führen Sie beide Kabelbinder durch die Schlitzte oben auf dem Kühlerschutz, dann um die oberen Kühlerschutzhalter, wie rechts abgebildet. Verwenden Sie die Originalschraube, um den Kühlerschutz unten am Originalhalter zu befestigen (siehe Abbildung oben links). Wenn der Kühlerschutz in der richtigen Position ist, ziehen Sie die Kabelbinder fest.