

Fitting Instructions for RAD0154 Radiator Guard KTM 990 ADVENTURE





PICTURE A



PICTURE B



PICTURE C



PICTURE D

In This Kit There Should Be 1x Radiator Guard 8x Cable/Zip Ties 2x 100mm Lengths of Foam

R&G Racing Unit 1, Shelleys Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0) 1420 89007 Fax: +44 (0) 1420 87301 Email: info@rg-racing.com



- Remove the two upper mounting bolts for the original plastic radiator guard.
- Remove the original plastic radiator guard.
- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator. Remove the two bolts in pictures A and B, offer radiator guard up to radiator and using original bolts secure the guard in place. Use two of the cable ties through the slots at the top of the guard and around the mounting brackets of the radiator see pictures C and D. When the guard is in position tighten all of the bolts and cable ties.

Issue 1 08/08/2013 (NSY)

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorised (if not pre-authorised the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.



Instructions de montage pour RAD0154 Grille de protection radiateur KTM 990 ADVENTURE





РНОТО А



РНОТО В



РНОТО С



PHOTO D

Le kit doit contenir : 1x Grille de protection 8x Colliers de serrage

R&G Racing Unit 1, Shelleys Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0) 1420 89007 Fax : +44 (0) 1420 87301 Email: info@rg-racing.com



2x 100mm Mousse autocollante

- Retirer les 2 boulons supérieurs de fixation de la protection d'origine.
- Retirer la protection en plastic d'origine.
- Couper la mousse en bandeaux de 10mm puis collez ces bandeaux au bas du support de protection radiateur, de façon à ce que ces bandeaux se situent entre la protection radiateur et le radiateur. Retirer les 2 boulons (Photos A et B). Poser la grille sur le radiateur en utilisant les boulons d'origine pour fixer la position. Poser 2 colliers de serrage aux slots sur le haut de la grille de protection et autour des supports de fixation du radiateur (Photos C et D). Lorsque la grille est en position, serrer tous les boulons et colliers de serrage.