



**FITTING INSTRUCTIONS FOR CP0049BL/WH & CP0094BL/WH CRASH PROTECTORS
YAMAHA R6 LOWERS**



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

Near side Bottom (left side as you sit on bike)

Remove Nylon Crash Protector from the Aluminium cup. Offer Aluminium cup up to near side swing arm pivot and position flush. Insert rawlbolt and torque up. Replace the Nylon Crash Protector.

Off side Bottom

Remove swing arm nut. Undo nylon crash protector from aluminium cup. Insert aluminium cup into swing arm pivot mount. Replace swing arm nut and torque to manufacturers recommended torque setting. Replace the nylon crash protector.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 5K, Blacknest Industrial Park, Blacknest Road, Alton, Hampshire, GU34 4PX

Tel: +44 (0)870 220 6380 Fax: +44 (0)1420 521101 www.rg-racing.com Email: info@rg-racing.com



Notice de montage

CP0049 YAMAHA 600 R6 99-02	
-----------------------------------	--

Le sens de montage n'est pas identique au sens présenté dans l'emballage, merci de suivre les instructions ci dessous.

Dans le cas où les kits sont emballés avec un joint torique, celui-ci doit être retiré avant le montage.

Conseil de montage:

GAUCHE:

- œ Dévissez le tampon en nylon de la pièce en alu (modèle sans la colerette).
- œ Positionnez la pièce en alu sur le côté gauche de la moto à l'arrière du cadre. (au niveau de la fixation du bras oscillant)
- œ Insérez la vis à travers la pièce en alu directement dans le cadre arrière.
- œ Attention de bien positionner les autres pièces de la vis dans le cadre. Car celle-ci doit se bloquer dans le cadre à mesure que la vis est serrée.
- œ Serrez la vis.
- œ Vérifiez que la pièce en alu soit correctement maintenue.
- œ Revissez le tampon en nylon sur la pièce en alu.

DROITE:

- œ Désérrez l'écrou de fixation de l'axe de bras oscillant.
- œ Enlevez ensuite le tampon de la protection (Avec la colerette)
- œ Positionnez la pièce en alu dans le logement de l'écrou de fixation.
- œ Remontez l'écrou et serrez le au couple d'origine.
- œ Revissez le tampon en nylon sur la pièce en alu.

R&G Racing

Unit 5K, Blacknest Industrial Park, Blacknest Road, Alton, Hampshire, GU34 4PX

Tel: +44 (0)870 220 6380 Fax: +44 (0)1420 521101 www.rg-racing.com Email: info@rg-racing.com