
#RAINLIGHT1 WWW.RG-RACING.COM



THE R&G RAIN LIGHT CAN EARTHED TO CHASSIS, LOOM OR DIRECT TO BATTERY

Circuit diagram



EARTH TO CHASSIS —— RAIN LIGHT — — SWITCH — - BATTERY -- FUSE -

The R&G Rain Light kit is for **RACE** and or **TRACK** use **ONLY**.

The kit is supplied with multiple fitting options. An inline fuse is included which should be used in all applications.

Fitting tips:

Drill pilot holes for the self tapping screw(s) to avoid cracking the plastic light housing or bodywork.

PLEASE NOTE: LEDs are polarity sensitive, ensure the light is wired the correct way round.

ENSURE LIGHT IS TESTED PRIOR TO FINAL INSTALLATION.

ALSO AVAILABLE FROM R&G













LEVER GUARD

AERO CRASH PROTECTORS ENGINE CASE COVERS

RADIATOR GUARDS

AERO KNEE SLIDERS Plus much more...



WWW.YOUTUBE.COM/USER/RANDGTV



WWW.FACEBOOK.COM/CRASHPROTECTION



WWW.TWITTER.COM/RNGRACING